

Note: Place a wire nut

on all unused wires

IT Room Solenoid Wiring Details

Note: Set to appropriate

point address

Relay

24vdc Aux Power-

SLC from FACP & AUX Pwr from NAC East

SHEET METAL SCREW - 2 PLACES

RTS151KEY ASSEMBLY NEAR RTU

REMOVE SNAP OFF TABS - 4 PLACES

PLACE JUMPER BETWEEN-

SYSTEM SENSOR DNR DUCT SMOKE DETECTOR (NOTE: BE SURE TO USE IDP PHOTOR HEAD AND PROGRAM APPROPRIATE POINT NUMBER)

SUPPLY DUCT SMOKE

**DETECTOR WIRING DIAGRAM** 

(with Relay Module)

AIR HANDLER UNIT

This Fire Alarm System sh installed in compliance wit NFPA72, 2013 ed, and all shall comply with NFPA70

LAST REVISION: 2/18/2021

BY: RGG

-Any additional color bands

EOL (End of Line) Resistor

Color Code

are insignificant for this purpose

CHECKED BY: PEH

FA-3

Sheet 3 of 7